




For Vent Wiring or controller/thermostat connections, see literature packet or go to www.bardhvac.com

WARNING
USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75° C.

DANGER
*ELECTRICAL SHOCK HAZARD
*DISCONNECT POWER BEFORE SERVICING.

A → **A**
Same Letter Designated Wires Connect if Option Not Used
"A" & "C" No Control Option
"B" Only Freeze Stat & No ODT

	Factory	Field	Optional
High Voltage			
Low Voltage			

Wire Identification numbers for Bard use only.
4217-203 A