



- ⚠ IF THERE IS AN X1 AND X2 TERMINAL ON (10) (11) (12), JUMPER THEM TOGETHER AND CONNECT FROM C TO EITHER ONE.
- ⚠ FOR 200V OPERATION MOVE THIS WIRE TO 200V TRANSFORMER TAP.
- ⚠ 400V5 - 40/400 CAPACITOR
 600V1 - 45/440 CAPACITOR

| | | |
|---|------------------------------------|-----------------------------|
| FACTORY WIRING Low Voltage High Voltage | FIELD WIRING ----- - - - - - | USE COPPER OR ALUMINUM WIRE |
|---|------------------------------------|-----------------------------|

Z3D-208-60-1

4089-111