



⚠ IF THERE IS AN X1 AND X2 TERMINAL ON OEM LABEL, JUMPER THEM TOGETHER AND CONNECT FROM C TO EITHER ONE

⚠ FOR 200V OPERATION MOVE THIS WIRE TO 200V TRANSFORMER TAP

FACTORY WIRING	FIELD WIRING	USE COPPER OR ALUMINUM WIRE
Low Voltage	High Voltage	