



- ⚠ IF THERE IS AN X1 AND X2 TERMINAL ON (874M1101), JUMPER THEM TOGETHER AND CONNECT FROM C TO EITHER ONE.
- ⚠ FOR LOW SPEED OPERATION, DISCONNECT THE BLACK MOTOR LEAD AND CONNECT IT TO THE ORANGE MOTOR LEAD. CONNECT THE RED MOTOR LEAD TO BLOWER RELAY TERMINAL NUMBER 1.

FACTORY WIRING Low Voltage High Voltage	FIELD WIRING USE COPPER OR ALUMINUM WIRE
---	---

4085-320 B