
REPLACEMENT PARTS MANUAL

Wall Mounted Packaged Air Conditioner

Models:

W18AF-A W24AF-A
 W24AF-B
 W24AF-C
 W24AF-D
 W24AF-F

General Notes

- Revised and/or additional pages may be issued from time to time.
- A complete and current manual consists of pages shown in the following contents section.

Important

- Contact the installing and/or local Bard distributor for all parts requirements. Make sure to have the complete model and serial number available from the unit rating plates.

Contents


Description	Page
Cabinet Components	
♦ Exploded View	2
♦ Usage List	3
♦ Usage List	4
Functional Components	
♦ Exploded View	6
♦ Usage List	7
Control Panel	
♦ Layout View	8
♦ Usage List	9
Blower Assembly	
♦ Exploded View	10
♦ Usage List	10



Bard Manufacturing Company, Inc.
Bryan, Ohio 43506
www.bardhvac.com

Manual: 2110-1481A
Supersedes: 2110-1481
Date: 9-19-25

CABINET COMPONENTS



This drawing to be used for reference for pages 3 and 4

SEXP-1102

CABINET COMPONENTS

Dwg No.	Part Number	Description	W18AF-A	W24AF-A	W24AF-B	W24AF-D	W24AF-C	W24AF-F
1	113-141-*BX ①	Top Rain Flashing	X	X	X	X	X	X
1	113-361BX ②	Top Rain Flashing	X	X	X	X	X	X
1	113-141-4BX ③	Top Rain Flashing	X	X	X	X	X	X
2	507-311-*BX ①	Top	X	X	X	X	X	X
2	507-318-*BX ③	Top	X	X	X	X	X	X
2	507-317BX ②	Top	X	X	X	X	X	X
3	123-126BX	Drain Pan	X	X	X	X	X	X
3	123-140BX ②③	Drain Pan	X	X	X	X	X	X
4	509-445BX	Upper Back	X	X	X	X	X	X
4	509-447BX ③	Upper Back	X	X	X	X	X	X
4	509-449BX ②	Upper Back	X	X	X	X	X	X
5	105-1302BX	Grommet Retainer	X	X	X	X	X	X
6	501-1204-*BX ①	Right Side	X	X	X	X	X	X
6	501-1205BX ②	Right Side	X	X	X	X	X	X
6	501-1206BX ③	Right Side	X	X	X	X	X	X
7	543-175-*BX ①	Right Side Cover Plate (Outer)	X	X	X	X	X	X
7	543-185BX ②	Right Side Cover Plate (Outer)	X	X	X	X	X	X
7	543-184BX ③	Right Side Cover Plate (Outer)	X	X	X	X	X	X
8	137X1101BX	Filter Fill Plate	X	X	X	X	X	X
9	131-196BX	Filter Partition Bracket	X	X	X	X	X	X
10	132-375BX	Control Panel Cover (Inner)	X	X	X	X		
10	132-385BX	Control Panel Cover (Inner)					X	X
11	113-140BX	Bottom Mounting Bracket	X	X	X	X	X	X
12	153-218-*BX ①	Disconnect Access Door	X	X	X	X	X	X
12	153-405BX ②	Disconnect Access Door	X	X	X	X	X	X
12	153-387BX ③	Disconnect Access Door	X	X	X	X	X	X
13	533-228-*BX ①	Control Panel Cover (Outer)	X	X	X	X	X	X
13	533-235BX ②	Control Panel Cover (Outer)	X	X	X	X	X	X
13	533-236BX ③	Control Panel Cover (Outer)	X	X	X	X	X	X
14	118-124-*BX ①	Side Grille	2	2	2	2	2	2
14	118-140BX ②	Side Grille	2	2	2	2	2	2
14	118-141BX ③	Side Grille	2	2	2	2	2	2
15	Control Panel Assembly	See Control Panel on pages 8 & 9	X	X	X	X	X	X
17	536-176BX	Cond. Partition Block Off Plate	X	X	X	X	X	X
17	536-878BX ②	Cond. Partition Block Off Plate	X	X	X	X	X	X
18	127-467BX	Lower Base	X	X	X	X	X	X
18	127-534BX ②	Lower Base	X	X	X	X	X	X
19	125-080BX	Fan Shroud	X	X	X	X	X	X
19	125-082BX ②	Fan Shroud	X	X	X	X	X	X
20	521X528BX	Condenser Partition	X	X	X	X	X	X
20	521-553BX ②	Condenser Partition	X	X	X	X	X	X
21	FAD-NE2	Fresh Air Damper Assembly	X	X	X	X	X	X
22	118-101-*BX ①	Condenser Grille	X	X	X	X	X	X
22	118-106BX ②	Condenser Grille	X	X	X	X	X	X
22	118-144BX ③	Condenser Grille	X	X	X	X	X	X
Continued on page 4								

① Exterior cabinet parts are manufactured with various paint color options. To ensure the proper paint color is received, include the complete model and serial number of the unit for which cabinet parts are being ordered.

② Exterior cabinet parts are manufactured from stainless steel Code "S"

③ Exterior cabinet parts are manufactured from aluminum Code "A"

CABINET COMPONENTS

Dwg No.	Part Number	Description	W18AF-A	W24AF-A	W24AF-B	W24AF-D	W24AF-C	W24AF-F
Continued from page 3								
23	553-537-*BX ①	Vent Option Door	X	X	X	X	X	X
23	553-547BX ②	Vent Option Door	X	X	X	X	X	X
23	553-548BX ③	Vent Option Door	X	X	X	X	X	X
23	553-539-*BX ①	Vent Option Door with ERV	X	X	X	X	X	X
23	553-555BX ②	Vent Option Door with ERV	X	X	X	X	X	X
23	553-556BX ③	Vent Option Door with ERV	X	X	X	X	X	X
23	553-666-*BX ①	Vent Option Door with CRV or ECON-S	X	X	X	X	X	X
23	553-692BX ③	Vent Option Door with CRV or ECON-S	X	X	X	X	X	X
23	553-693BX ②	Vent Option Door with CRV or ECON-S	X	X	X	X	X	X
24	553-538-*BX ①	Filter Door	X	X	X	X	X	X
24	553-552-*BX ③	Filter Door	X	X	X	X	X	X
24	553-551BX ②	Filter Door	X	X	X	X	X	X
25	514-240-*BX ①	Upper Front	X	X	X	X	X	X
25	514-237-*BX ③	Upper Front	X	X	X	X	X	X
25	514-236BX ②	Upper Front	X	X	X	X	X	X
26	121X480BX	Blower Partition	X	X	X	X	X	X
27	105X850BX	Side Support	X	X	X	X	X	X
28	137-694BX	Bottom Evaporator Fill	X	X	X	X	X	X
29	501-1219-*BX ①	Left Side	X	X	X	X	X	X
29	501-1210BX ②	Left Side	X	X	X	X	X	X
29	501-1211BX ③	Left Side	X	X	X	X	X	X
30	147-044BX	Evaporator Support	X	X	X	X	X	X
31	111X032BX	Outlet Air Frame Assembly	X	X	X	X	X	X
32	135X127BX	Heat Shield	X	X	X	X	X	X
33	109-444BX	Lower Back	X	X	X	X	X	X
33	109-446BX ③	Lower Back	X	X	X	X	X	X
33	109-448BX ②	Lower Back	X	X	X	X	X	X
34	131-192BX	Filter Tray Angle	X	X	X	X	X	X
35	131X191BX	Filter Partition	X	X	X	X	X	X
NS	5252-033	Bard Nameplate	X	X	X	X	X	X

① Exterior cabinet parts are manufactured with various paint color options. To ensure the proper paint color is received, include the complete model and serial number of the unit for which cabinet parts are being ordered.


② Exterior cabinet parts are manufactured from stainless steel Code "S"

③ Exterior cabinet parts are manufactured from aluminum Code "A"

Refer to drawing on page 2

This page intentionally left blank

FUNCTIONAL COMPONENTS



FUNCTIONAL COMPONENTS


Dwg No.	Part Number	Description	W18AF-A	W24AF-A	W24AF-B	W24AF-C	W24AF-D	W24AF-F
1	900-358-0148BX	Blower Assembly		X	X		X	X
1	900-359-0149BX	Blower Assembly				X		
1	900-358-0147BX	Blower Assembly	X					
2	917-0539BX	Evaporator Coil with Distributor Assembly	X					
2	917-0540BX	Evaporator Coil – Coated with Distributor Assembly	X					
2	917-0537BX	Evaporator Coil with Distributor Assembly		X	X	X	X	X
2	917-0538BX	Evaporator Coil – Coated with Distributor Assembly		X	X	X	X	X
3	800-0502BX	Distributor Assembly	X					
3	800-0503BX	Distributor Assembly		X	X	X	X	X
4	1171-023	1/4" Receptacle	X	X	X	X	X	X
5	1171-024	1/4" Turn Retainer	X	X	X	X	X	X
6	1171-022	1/4" Turn Fastener	X	X	X	X	X	X
7	8103-028BX	Condenser Motor	X	X	X			
7	8103-030BX	Condenser Motor				X		
7	8105-080BX	Condenser Motor					X	X
8	8200-001BX	Fan Motor Mount	X	X	X	X	X	X
8	8200-050 BX ①	Stainless Steel Fan Motor Mount	X	X	X	X	X	X
9	5151-033BX	Fan Blade	X	X	X		X	X
9	5151C003BX ①	Coated Fan Blade	X	X	X		X	X
9	5151-046BX	Fan Blade				X		
9	5151C046BX ①	Coated Fan Blade				X		
10	CMC-31	Dirty Filter Switch Kit	X	X	X	X	X	X
11	CMA-37	Modulating Low Ambient Control (Screw On) ②	X	X	X		X	X
11	CMA-38	460V Modulating Low Ambient Control ②				X		
12	8000-485BX	Compressor	X					
12	8000-486BX	Compressor		X				
12	8000-487BX	Compressor			X			
12	8000-488BX	Compressor				X		
12	8000-493BX	Compressor					X	
12	8000-492BX	Compressor						X
13	5051-205BX	Condenser Coil	X					
13	5054-205BX	Condenser Coil – Coated	X					
13	5051-204BX	Condenser Coil		X	X	X	X	X
13	5054-204BX	Condenser Coil – Coated		X	X	X	X	X
14	7004-011	Air Filter 1" Throw-Away (16x25x1)	X	X	X	X	X	X
14	7003-032	Air Filter 1" Washable ② (16x25x1)	X	X	X	X	X	X
14	7004-025	Air Filter 2" Pleated ② (16x25x2)	X	X	X	X	X	X
14	7004-059	Air Filter 2" Pleated – MERV 11 ② (16x25x2)	X	X	X	X	X	X
14	7004-061	Air Filter 2" Pleated – MERV 13 ② (16x25x2)	X	X	X	X	X	X
15	8301-110BX	RDS Sensor	X	X	X	X	X	X
NS	8401-036BX	RDS Relay	X	X	X	X	X	X
NS	8406-167BX	High Pressure Switch (Screw On)	X	X	X	X	X	X
NS	8406-166BX	Low Pressure Switch (Screw On)	X	X	X	X	X	X
NS	5201-021BX	Filter Drier	X	X	X	X	X	X
NS	5451-024	Tubing Isolation Grommet	X	X	X	X	X	X
NS	6031-009	Coremax Valve Core	X	X	X	X	X	X
NS	1171-028	Filter Door Clip	2	2	2	2	2	2
NS	1171-057	Filter Door Screw	2	2	2	2	2	2
NS	1171-027	Filter Door Screw Retainer	2	2	2	2	2	2
NS	CMC-29	Freeze Thermostat Kit	X	X	X	X	X	X

NS – Not Shown

① – Used with stainless steel cabinet option

② – Optional on these models

CONTROL PANEL



SEXP-908 A


CONTROL PANEL

Dwg No.	Part Number	Description	W18AF-A	W24AF-A	W24AF-B	W24AF-C	W24AF-D	W24AF-F
1	117X137BX	Control Panel Top	X	X	X	X	X	X
2	117X447BX	Control Panel	X	X	X	X	X	X
3	8407-068BX	Transformer	X	X	X		X	X
3	8407-069BX	Transformer				X		
4	8611-006	Ground Terminal	X	X	X	X	X	X
5	8401-033BX	Compressor Contactor	X	X			X	
5	8401-035BX	Compressor Contactor			X	X		X
6	135-122BX	Wire Shield	X	X	X	X	X	X
7	8201-176BX	Compressor Control Module	X	X	X	X	X	X
9	8607-017BX	Terminal Block (Optional)	X	X	X	X	X	X
10	8552-047BX	Compressor Capacitor	X	X			X	
10	8552-002BX	Outdoor Motor Capacitor			X	X		X
11	8201-130BX	Alarm Relay (Optional)	X	X	X	X	X	X
12	8551-004BX	Start Device (PTCR) (Optional)	X	X			X	
13	8607-063BX	Low Voltage Terminal Strip	X	X	X	X	X	X
14	8611-140-1400	Cable Duct – 14" Piece	X	X	X	X	X	X
14	8611-140-0500	Cable Duct – 5" Piece	X	X	X	X	X	X
15	8201-174BX	Phase Monitor			X	X		X
16	8607-042	Blower Speed Terminal	X	X	X	X	X	X
17	8201-130BX	Blower Control Relay	X	X	X	X	X	X
18	141-595BX	Plug Support Bracket	X	X	X	X	X	X
NS	3000-1598BX	Blower Power Plug	X	X	X	X	X	X
NS	3000-1607BX	Blower Speed Plug	X					
NS	3000-1599BX	Blower Speed Plug		X	X	X	X	X
NS	3000-1524BX	Vent Jumper Plug	X	X	X	X	X	X
NS	8615-035BX	Circuit Breaker 20A 2 Pole (Opt.) ①	X					
NS	8615-036BX	Circuit Breaker 25A 2 Pole (Opt.) ①		X			X	
NS	8615-095BX	Toggle Disconnect (Optional) ①				X		X
NS	8615-054BX	Circuit Breaker 20A 3 Pole (Opt.) ①			X			
NS	8607-017BX	Terminal Block 2 Pole						X
NS	113-601BX	Terminal Block Bracket						X
NS	4213-130	Wiring Diagram	X					
NS	4213-128	Wiring Diagram		X			X	
NS	4213-228	Wiring Diagram			X			
NS	4213-330	Wiring Diagram				X		
NS	4213-628	Wiring Diagram						X
NS	3000-1224BX	Compressor Plug/Harness	X	X			X	
NS	3000-1231BX	Compressor Plug/Harness			X	X		X
NS	3003-150BX	Control Panel Harness		X			X	
NS	3003-151BX	Control Panel Harness			X	X		
NS	3003-152BX	Control Panel Harness						X
NS	3003-155BX	Control Panel Harness	X					
NS	3000-1608BX	Low Voltage Terminal Block Harness	X	X	X	X	X	X
NS	910-2047BX	Complete Low Voltage Box Assembly (Sheet Metal, LVTS & Wire Harness)	X	X	X	X	X	X

NS = Not Shown

① Circuit breakers listed are for units without electric heat, "OZ" models. See heater replacement parts manual for units with electric heat.

BLOWER ASSEMBLY



SEXP-909

Dwg No.	Part Number	Description	900-358-0147BX	900-358-0148BX	900-359-0149BX
1	8105-064-0147BX	Blower Motor & Control (230/208V)	X		
1	8105-064-0148BX	Blower Motor & Control (230/208V)		X	
1	8105-065-0149BX	Blower Motor & Control (460V)			X
2	151-115BX	Housing	2	2	2
3	144-183BX	Cutoff	X	X	X
4	5152-092BX	Wheel 9-6 CW	X	X	X
5	5152-093BX	Wheel 9-6 CCW	X	X	X
6	105-1061BX	Back Brace	X	X	X
7	5451-011	Grommets	6	6	6
8	8200-031BX	Motor Mount	X	X	X
9	103-435BX	Front Brace	X	X	X
10	113-721BX	Motor Control Bracket	X	X	