




⚠ See alternate thermostat sheet.

⚠ For 208V operation move this wire to 100V transformer tap.

⚠ For low speed operation, disconnect the black motor lead and connect it to the orange motor lead. Connect the red motor lead to blower relay terminal number 1.

501962