


Immersion
Crankcase
Heater



- ⚠ Add jumper R_c to R_h. Set heat anticipators at .40A for W1 and W2.
- ⚠ Remove jumper W1-W2 for 2-stage heat.
- ⚠ For 208V operation move this wire to 208V transformer tap.