

⚠ 2nd heat contactor operated only during emergency heat or compressor cutoff.

⚠ For 200V operation move this wire to 200V transformer tap.

