



⚠ IF THERE IS AN XT AND R2 TERMINAL ON INSTALLATION, JUMPER THEM TOGETHER AND CONNECT FROM C TO EITHER ONE

⚠ FOR 200V OPERATION NOW, THIS WIRE TO 200V TRANSFORMER TAP

FIGURE A - 60A TIME RELAY
 FIGURE B - 60A STANDARD
 ALL FUSES CLASS RS

⚠ 400MS - 40/440 CAPACITOR
 600MS - 45/440 CAPACITOR

FACTORY WIRING **FIELD WIRING**

Low Voltage High Voltage

USE COPPER OR ALUMINUM WIRE