



NOTE:
 BARD 8403-083-005 CONTROLLER
 MUST BE USED WITH THESE
 UNITS. A THERMOSTAT WILL NOT WORK.

| | | | | |
|---|--|-------|----------|--|
| <p>A</p> <p>Wires Connect if Option Not Used</p> | <p>99 Wire Identification numbers for Bard use only.</p> | | | <p>WARNING</p> <p>USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75° C.</p> |
| | Factory | Field | Optional | |
| High Voltage | ----- | ----- | ----- | <p>DANGER</p> <p>ELECTRICAL SHOCK HAZARD DISCONNECT POWER BEFORE SERVICING.</p> |
| Low Voltage | ----- | ----- | ----- | |

4095-375 H