



NOTE:
 BARD 8403-066 CONTROLLER
 MUST BE USED WITH THESE
 UNITS. A THERMOSTAT WILL NOT WORK.

Wires Connect if Option Not Used	Wire Identification numbers for Bard use only.		
	Factory	Field	Optional
High Voltage	---	---	---
Low Voltage	---	---	---

WARNING
 USE COPPER CONDUCTORS
 ONLY SUITABLE FOR AT LEAST
 75° C.

DANGER
 ELECTRICAL SHOCK HAZARD
 DISCONNECT POWER BEFORE
 SERVICING.