




For Vent Wiring or controller/thermostat connections, see literature packet or go to www.bardhvac.com

115-60-1
Per Nameplate

L1
N

Hi Voltage Field Connection

Hi Voltage Field Connection

Compressor Contactor

Low Ambient Control (opt.)

Compressor

Outdoor Fan Motor

Hi Press. Control

Low Press. Control

Outdoor Temp Switch (Opt.)

Condenser Section

WARNING
USE COPPER CONDUCTORS
ONLY SUITABLE FOR AT LEAST
75° C.

DANGER
ELECTRICAL SHOCK HAZARD
*DISCONNECT POWER BEFORE
SERVICING.

Wires Connect if Option Not Used

	High Voltage	Low Voltage

Wire Identification numbers for Bard use only.		
Factory	Field	Optional