



For Vent Wiring or controller/thermostat connections, see literature packet or go to www.bardhvac.com

NOTE: THESE ARE LOCATED IN UPPER CONTROL PANEL ON THE W42-72 BROWN OR BLACK ON W24 MODELS BLUE OR WHITE ON W24 UNITS

NOTE: Motor powered with Black and Red (Power) leads. W24-60 50Hz: Low Voltage Yellow Wire on Parking Terminal. W72 50Hz: Low Voltage Blue Wire on Parking Terminal (Swap with Yellow)

WARNING
USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75° C.

DANGER
ELECTRICAL SHOCK HAZARD
DISCONNECT POWER BEFORE SERVICING.

NOTE: JUMPER PLUG MUST BE INSTALLED WHEN NO VENT OPTION IS INSTALLED

Wire Identification numbers for Bard use only.

	Factory	Field	Optional
High Voltage			
Low Voltage			

4213-628 C