













TB74N1024/
Q674F1262

or

TB74N1129/
Q674F1181

⚠ For low speed operation, disconnect the black motor lead and connect it to the orange motor lead. Connect the red motor lead to blower relay terminal number 1.

⚠ REPLACE FUSE WITH "BUSS AGC 3" 3 AMP FUSE RATED 250V or LESS

4013-321E

