

USE COPPER CONDUCTORS ONLY

- ⚠ See alternate thermostat sheet.
- ⚠ For 208V operation move this wire to 208V transformer tap.


Fused Disconnect Switch

210/208-60-1

MODEL 24WA4

FACTORY WIRING	FIELD WIRING
Low Voltage ———	-----
High Voltage ———	-----

4007-113A



Equip. Ground

USE COPPER CONDUCTORS ONLY

Fused Disconnect Switch


230/208-60-1

⚠ See alternate thermostat sheet.
 ⚠ For 208V operation move link wire to 208V transformer tap.

MODEL 24WA4

FACTORY WIRING	FIELD WIRING
Low Voltage ———	-----
High Voltage ———	-----


4007-114A



MODEL
24MA4

FACTORY WIRING	FIELD WIRING
Low Voltage	-----
High Voltage	-----

4007-115




USE COPPER CONDUCTORS ONLY

- ⚠ See alternate thermostat sheet.
- ⚠ For 208V operation move links wire to 208V transformer tap.

MODEL 24MA4

FACTORY WIRING	FIELD WIRING
Low Voltage ———	—————
High Voltage ———	—————

4007-116




USE COPPER OR ALUMINUM WIRE

- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A.
- ⚠ For 208V operation move this wire to 208V transformer tap.

MODEL
24WA4
w/ 1/4
OR 5K

FACTORY WIRING	FIELD WIRING
Low Voltage	-----
High Voltage	-----

4007-123A




USE COPPER OR ALUMINUM WIRE

- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A.
- ⚠ For 208V operation move this wire to 208V transformer tap.

MODEL
24WA4
W/ 4
OR 5K

FACTORY WIRING	FIELD WIRING
Low Voltage	-----
High Voltage	-----

4007-124A




USE COPPER OR ALUMINUM WIRE

- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A.
- ⚠ For 208V operation move this wire to 208V transformer tap.

230/208-60-1

MODEL
24VAA
w/ 4
OR 5Kv

FACTORY WIRING	FIELD WIRING
Low Voltage	-----
High Voltage	-----



USE COPPER OR ALUMINUM WIRE


- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A.
- ⚠ For 208V operation move this wire to 208V transformer tap.

230/208-60-1

MODEL
24VAA
w/ 4
OR 5KW

FACTORY WIRING	FIELD WIRING
Low Voltage ———	-----
High Voltage ———	-----

4007-126




USE COPPER OR ALUMINUM WIRE.

- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A.
- ⚠ For 208V operation move this wire to 208V transformer top.

MODEL
24WA4
w/ 8
OR 10KW

4007-133A




USE COPPER OR ALUMINUM WIRE

⚠ See alternate thermostat sheet. Set heat anticipator at .40A.

⚠ For 208V operation move this wire to 208V transformer tap.

MODEL
24WA4
w/ 8
OR 10KW

4007-134A




230/208-60-1

USE COPPER OR ALUMINUM WIRE

- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A.
- ⚠ For 208V operation move this wire to 208V transformer tap.

MODEL
24WA4
w/ 8
OR 10KW

4007-135



230/208-60-1


USE COPPER OR ALUMINUM WIRE

⚠ See alternate thermostat sheet. Set heat anticipator at .40A.

⚠ For 208V operation move this wire to 208V transformer tap.

MODEL
24WA4
w/ 8
OR 10KW

4007-136



Fused Disconnect Switch

230/208-60-3

USE COPPER OR ALUMINUM WIRE

- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A.
- ⚠ For 208V operation move this wire to 208V transformer tap.

FACTORY WIRING	FIELD WIRING
Low Voltage ———	-----
High Voltage ———	-----

Model
24WA9
w/6 or 9Kw