


**USE COPPER CONDUCTORS ONLY**

- ⚠ See alternate thermostat sheet. Set heat anticipator at .40A
- ⚠ Not all outdoor motors employ capacitor. Motors without capacitor are two-wire and hook directly to T1 and 4.

Model 36NR

Factory Wiring \_\_\_\_\_  
Field Wiring - - - - -




- ⚠ Set heat anticipator at .40A
- ⚠ Add jumper Rc to Rh.
- ⚠ Not all outdoor motors employ capacitor. Motors without capacitor are two-wire and hook directly to T1 and 4.

USE COPPER OR ALUMINUM WIRE

Factory Wiring ———  
Field Wiring - - - - -

Model 36WH  
w/12 or 15Kw



Fused Disconnect Switch

USE COPPER OR ALUMINUM WIRE

240V 60 Hz 3-Ph

Factory Wiring  
Field Wiring

- ① Set heat anticipator at .40A.
- ② Add jumper Rc to Rh.
- ③ Not all outdoor motors employ capacitor. Motors without capacitor are two-wire and hook directly to T1 and 4.

Model  
36WH  
w/9Kw